



Starting the engine

1. Push the primer 1 or 2 times until fuel is visible in the primer.
(When the tank was empty more repetition is necessary.)
2. Push the choke lever to the close position. 
3. Pull the starter handle only one time firmly.
4. Push the choke lever to the open position. 
5. Pull the starter handle firmly until the motor starts.

! If engine is already hot do not use choke!

For more information read the manual